


541-356 Adjustable Basketball Backstop Fiberglass Backboard

Page 1
Rev. 09/27/2004

IMPORTANT

PLEASE READ THESE INSTRUCTIONS BEFORE COMMENCING ASSEMBLY. All equipment must be installed in accordance with these instructions. Check your shipment against Bill of Lading and Parts list. Any missing or broken parts must be reported to your distributor within 10 days of receipt of your order. When properly installed and maintained, equipment will give many years of Safe, Trouble-Free use. Periodically check for loose or broken parts. Loose bolts must be tightened and broken parts must be replaced as they can possibly create dangerous situations leading to unnecessary accidents.



PACKING LIST

1	CTN	1	Hardware Bag
		1	545-917 Official Goal
		1	545-902 Nylon Net
1	CTN	1	533-930 Fiberglass Board
1	PIPE	1	543-553 Adjustable Bracket
1	PIPE	1	543-603 3 1/2" x 13' Long Pipe

HARDWARE BAG

1	105-018	3 1/2" Pipe Plug
2	196-803	1/2" x 3/4" Socket Set Screw
4	116-608	3/8" x 2" Hex Hd Bolt
4	316-601	3/8" Flat Washer
4	216-601	3/8" Hex Nuts
1	416-400	1/4" Socket Key

2 CTN	2 PIPE	4 TOTAL PCS	130# Weight	Class 70
-------	--------	-------------	-------------	----------

541-356 Adjustable Basketball Backstop
Fiberglass Backboard

Page 2
Rev. 09/27/2004

ASSEMBLY AND INSTALLATION:

NOTE: All threaded ends of bolts protruding beyond nuts must be cut off and/or peened to eliminate sharp edges. No more than two threads should extend beyond face of nut. All washers, "T" nuts, and other fastener hardware used on round pipe or tubing must be hammered down to conform to the curved underlying surface to eliminate catch points. DO NOT tighten nuts more than hand-tight until entire assembly is completed.

STEP #1: Locate and dig footing hole for 543-603 galvanized pipe 3 ½" x 13' Long.

NOTE: see illustration on page 1 for size and depth of footing hole

STEP #2: Attach 543-553 Adjustable Bracket to one end of 543-603 Galvanized Pipe using:

2 - ½" x ¾" Set Screws
1 - ¼" Socket Key

STEP #3: Place 543-603 Post into footing hole.

NOTE: Brace 543-603 Post in footing hole so that the open end of the post is approximately 6" from the bottom of the footing hole. IT IS CRITICAL to maintain the 9'8" dimension from the underside of the adjustable bracket to the top of the playing surface.

STEP #4: Mix and pour concrete into footing hole using:

6 - 80 lb. Bags of Pre-Mix cement.

NOTE: Fill footing hole to the top with concrete and crown top for drainage.

STEP #5: Attach Goal and Net to 533-930 fiberglass backboard to 543-553 Adjustable bracket using:

4 - 3/8" x 2" Hex Bolts
4 - 3/8" Flat Washers
4 - 3/8" Hex Nuts

STEP #6: Allow at least 48 hours for concrete to harden before using backstop for regular play.

NOTES: Fiberglass backboard has inlaid border and target.
Do NOT over tighten bolts.
The official height of a Goal & Net is 10 feet from top of rim to top of playing surface.

Maintenance: Check periodically for loose bolts and/or broken parts.
Replace immediately.