

302-141 RABBIT HUTCH (PORTABLE)


Page 1 of 3
Rev 4/1/03

IMPORTANT

PLEASE RETAIN THIS INFORMATION SHEET IN YOUR FILES. IT CONTAINS IMPORTANT REPLACEMENT PARTS INFORMATION. ALL EQUIPMENT SHOULD BE INSTALLED IN ACCORDANCE WITH THESE INSTRUCTIONS.

IT IS IMPORTANT TO USE AND MAINTAIN ALL PUBLIC PLAYGROUND EQUIPMENT PROPERLY. PLAYGROUND EQUIPMENT, WHICH IS IMPROPERLY MAINTAINED, CAN CAUSE SERIOUS INJURY. PERIODICAL INSPECTIONS, MAINTENANCY, REPAIR AND/OR REPLACEMENT OF DAMAGED PARTS IS NECESSARY FOR SAFE OPERATION OF EQUIPMENT. APPROPRIATE PUBLICATIONS, AVAILABLE AT NO CHARGE, FROM THE CONSUMER PRODUCT SAFETY COMMISSION, INCLUDE A "HANDBOOK FOR PUBLIC PLAYGROUND SAFETY."

YOU CAN RECEIVE YOUR FREE COPY BY CALLING TOLL FREE 1-800-727-8180



PACKING LIST

1 CTN - 1 Hardware Bag
1 CTN - 1 113-306 2-Ring Ladder
1 Shell - 1 113-044 Shell

HARDWARE BAG

4 - 303-901 Shell Leg
4 - 315-961 Black Cap
4 - 116-608 3/8" x 2" Hex Head Bolt
4 - 116-535 5/16" x 1 1/2" Button Hd Bolt
4 - 216-512 5/16" Button Hd Nut
4 - 326-501 5/16" Lock Washer
2 - 416-350 3/16" Socket key
4 - 326-601 3/8" Lock Washer

2 CTN	1 SHELL	3 TOTAL PCS	WT 160#	CLASS 70
-------	---------	-------------	---------	----------


302-141 RABBIT HUTCH (PORTABLE)

Page 2 of 3
Rev 4/1/03


GENERAL USE/FALL ZONE & FOOTING RECOMMENDATIONS

STATIONARY & PORTABLE EQUIPMENT – USE/FALL ZONES SHOULD EXTEND A MINIMUM OF 6 FEET IN ALL DIRECTIONS FROM THE PERIMETER OF THE EQUIPMENT GROUND SPACE. THIS AREA SHOULD BE COVERED WITH THE REQUIRED AMOUNT OF RESILIENT SAFETY SURFACING MATERIAL. FOR SOME EQUIPMENT – USE/FALL ZONES CAN OVERLAP. SEE CONSUMER PRODUCT SAFETY COMMISSION GUIDELINES. DIAMETER & DEPTH OF FOOTINGS ILLUSTRATED ARE SATISFACTORY IN MOST APPLICATION FOR PIPE SIZES UP TO 2 3/8" DIAMETER. VARYING SOIL & CLIMATIC CONDITIONS MAY REQUIRE DEEPER & HEAVIER FOOTINGS IN SOME AREAS. CHECK LOCAL BUILDING CODES.

PERMANENT IN-GROUND INSTALLATION:



USE AREA & FOOTING LAYOUT:



USE AREA: 17' x 17'

NOTE: The suggested use area should be covered with a shock absorbent material. No other piece of equipment or its use area should encroach on this use area.

GENERAL ASSEMBLY INSTRUCTIONS:

Check all the parts and hardware with the packing list to be sure you have received everything needed to assemble this product. CONTACT YOUR LOCAL DISTRIBUTOR WITH NOTIFICATION OF ANY MISSING OR DAMAGED PARTS. Contact must be made within ten days of receipt of your order.

Only hand-tighten nuts & bolts on initial assembly. Final tightening should be done **EVENLY** after final assembly when unit has been plumbed & leveled. After assembly is complete, **ANY ENDS OF BOLTS PROTRUDING BEYOND NUTS SHOULD BE CUT OFF AND/OR PEENED OVER TO REMOVE ANY SHARP PROJECTIONS.** Go over entire unit to file smooth any sharp edges or projections that may have been caused by rough handling in shipping or installation.

302-141 RABBIT HUTCH (PORTABLE)

Page 3 of 3
Rev 4/1/03

GENERAL MAINTENANCE INSTRUCTIONS:

Check MONTHLY for loose bolts, damaged or broken parts. Tighten and/or replace immediately.

SPECIFIC ASSEMBLY INSTRUCTIONS:

- STEP #1** Place 113-306, 2-Ring Ladder onto ground with ring that has (4) holes in it facing upwards.
- STEP #2** Invert – 113-044 Shell, turning it up-side down, placing it on top of 2-Ring Ladder.
- STEP #3** Attach 2-Ring Ladder to Shell using 5 / 16" x 1 – ½" Button Head Bolts, 5 / 16" Lock Washers, and 5 / 16" Button Head Nuts. Tighten Button Head Bolts and Nuts with 3/16" Socket Key.
- STEP #4** Install Black Plastic Caps over open end of 303-901 Legs.
- STEP #5** Attach 303-901 Shell Legs to Shell using 3 / 8" x 2" Hex Head Bolts with 3 / 8" Lock Washers.
- STEP #6** Check and tighten all Bolts and Nuts.
- STEP #7** Place completed assembly right side up and position in place as required.

Note: All threaded ends of bolts protruding beyond nuts must be cut off and/or peened to eliminate sharp edges. No more than two threads should extend beyond face of nut.

All washers, "T" nuts, and other fastener hardware used on round pipe or tubing must be hammered down to conform to the curved underlying surface to eliminate catch points.